



CP3 REGULATOR EXTRACTOR



P.N.: ECP3

The extractor is meant to separate regulator into different parts so to perform an internal check over and even a calibration if required. This is carried out through the shims that can be exchanged each other even their applications and codes differ from the original ones.

